

Nemox SIP-Trunk



Routes - SIP gateways

Title:	Nemox	sip.conf:
Name:	gw_5_nemox	[peer-name]
Registrar / Server:	sip.nemox.net	host
Proxy [1]:		outboundproxy
Username [2]:	00000_1	defaultuser / fromuser@fromdomain
Password:	■■■■■	secret
Authuser [3]:		authuser
	<input checked="" type="checkbox"/> permit outbound calls <input checked="" type="checkbox"/> register	..., register
Language:	de - German (de-DE) ▾	language = de en
Dial() argument [4]:	SIP/{number:1}@{gateway}	~ Dial(SIP/...)
Extract target number from:	to-header - Extract target number from SIP `to` header ▾	
Group [5]:	Amt ▾	context = from-gg-amt
Port [6]:	5060 (Default: 5060)	port
Is behind NAT:	<input checked="" type="radio"/> yes <input type="radio"/> no <input type="radio"/> Force rport <input type="radio"/> comedia only (Default: yes)	nat = yes no force_rport comedia
Reroute RTP stream:	no - Don't reroute RTP stream (default) ▾	directmedia = no yes nonat update update,nonat
Monitor availability:	<input checked="" type="radio"/> yes <input type="radio"/> no (Default: yes)	qualify = yes no
Simultaneous calls:	0 (0 for unlimited, Default: 0)	call-limit
DTMF mode:	rfc2833 - RTP meta data ▾ (Default no.: rfc2833)	dtmfmode
Insecure:	invite - no authentication on incoming invites ▾	insecure = no port invite port,invite
Update Remote-Party-ID:	no - Deactivated (default) ▾	sendrpid = no yes pai
Trust Remote-Party-ID:	no - Deactivated (default) ▾	trustrpid = no yes
Codecs:	<input checked="" type="checkbox"/> G.711a <input type="checkbox"/> G.711u <input type="checkbox"/> GSM <input type="checkbox"/> H.261 <input type="checkbox"/> H.263 <input type="checkbox"/> H.263+ (Default: G.711a)	allow
Permit IP subnet [7]:	0.0.0.0/0 (Default: 0.0.0.0/0)	permit

Inbound DID

Die Angerufene Nummer hat folgendes Format: +43...



Routes - Gateway groups

Gateway group:

Gateway group

Title:	<input type="text" value="Amt"/>
Type:	<input type="text" value="Load Balance"/>
	<input checked="" type="checkbox"/> permit inbound calls
Outbound caller-ID:	Search/replace pattern for outbound caller ID [1] : s/ <input type="text" value="^([0-9][0-9][0-9]?)\$"/> / <input type="text" value="004312996053\$1"/> /
Deactivate rewriting:	Search pattern to deactivate rewriting: s/ <input type="text" value=""/> /
Inbound DIDs:	Search/replace pattern (to cut prefixes) [2] : s/ <input type="text" value="^\+4312996053 (.*)\$"/> / <input type="text" value="\$1"/> /
Inbound caller-ID:	Search/replace pattern [3] : s/ <input type="text" value="^(.*)"/> / <input type="text" value="0\$1"/> /

Gateways

Type	Title
SIP	Amt
SIP	Nemox

From: <https://wiki.ucware.com/> - UCware-Dokumentation

Permanent link: <https://wiki.ucware.com/gateway/sip/nemox?rev=1667308667>

Last update: 18.03.2023 14:47

