

SANAL SANTRAL TELEKOMUNİKASYON TİC. A.Ş.

	Wert
Registrar / Server	sp.sanal.link
Username	<html><user></html>
Password:	<html><pass></html>
Authuser	
Insecure	port, invite



Gatewaygruppe



Vollständige Peerconfig:

```
[gw_2_sanal]
type = peer
host = sp.sanal.link
port = 5060
defaultuser = 902327000101
secret = MpH0t3l48S1p
language = de
insecure = port,invite
sendrpid = no
trustrpid = no
nat = yes
directmedia = no
dtmfmode = rfc2833
call-limit = 0
setvar=__is_from_gateway = 1
context = from-gg-sanal
qualify = yes
disallow = all
allow = alaw
```

From:

<https://wiki.ucware.com/> - UCware-Dokumentation

Permanent link:

<https://wiki.ucware.com/gateway/sip/sanal?rev=1548764688>

Last update: **18.03.2023 14:47**